
From: [REDACTED]
Sent: Saturday, September 15, 2012 6:07 PM
To: Je vacation
Subject: Living room

Jeffrey,

I turned down the output Gain on the processor slightly, it was set very high, also turned down main output of crown Amps one notch. I played the system for 45min and didn't hear any clipping.

If memory servers correctly, the clipping is due to high gain to speakers.

I also notice the bypass button was pressed on the processor, this may have aided in clipping.

-also the tambourine on the L/H sub woofer would rattle during low bass music. I thought the speaker was blown,..

Let me know when I'm able to address gym?

Thx

Larry

Sent via BlackBerry by AT&T

```
<?xml version="1.0" encoding="UTF-8"?>
<!DOCTYPE plist PUBLIC "-//Apple//DTD PLIST 1.0//EN" "http://www.apple.com/DTDs/PropertyList-1.0.dtd">
<plist version="1.0">
<dict>
    <key>conversation-id</key>
    <integer>231181</integer>
    <key>date-last-viewed</key>
    <integer>0</integer>
    <key>date-received</key>
    <integer>1347732393</integer>
    <key>flags</key>
    <integer>8623750145</integer>
    <key>gmail-label-ids</key>
    <array>
        <integer>6</integer>
        <integer>2</integer>
    </array>
    <key>remote-id</key>
    <string>246123</string>
</dict>
</plist>
```