


HIGH ROLLING SCAFFOLDS

(Towers requiring extended base dimensions)

Free-standing rolling scaffolds must be guyed, tied to a solid structure or, the maximum platform height must not exceed 4 times * the narrowest base dimension with outriggers.

*Some state OSHA regulations may have other limiting height/base ratios such as 3:1 in CA, OH, OR, MT and ME - 3.5:1 in WA. Check and comply with your local state/OSHA regulations.



1. When base extensions (outriggers) are required, attach them to end frames before assembling first unit.
2. Assemble the first unit. Place end frame sections **A** of the next unit (dowel ends upward) over dowels that are in top ends of end frame sections first assembled. Pin sections together with snap pins. Alternatively, arm braces **B** may be assembled so that they overlap the joint of the two end frame sections to prevent separation.
3. Place platforms in position on each unit to provide footing for placing next unit and to make a rigid scaffold.
4. Additional arm braces shall be placed as near the bottom of the assembly as possible for added rigidity to the assembly and are required for all high assemblies.

